

# ME30W Conference Microphones

- Capture sound in large gatherings
- Tripods included, easy set up
- 2 omni-directional high quality microphones



## Ideal for recording conferences

For meetings, conferences and concerts, with the ME-30W Conference Microphones, it is easier than ever to capture sounds in large gatherings, all in high quality stereo. This professional solution includes two omni-directional microphones engineered by Olympus for seamless compatibility. With 360° coverage, you'll never miss a contribution - no matter where the speaker is sitting. These left and right channel, low-noise stereo microphones cover a 20Hz - 20,000Hz frequency bandwidth and can be attached to two foldable mini tripods which are included in the kit. For maximum coverage, they can be placed up to 5 metres (16ft) apart – perfect for recording in large rooms, concert venues or when many participants are sitting around a very large table. The ME-30W Conference Microphone Kit includes a soft carry case that keeps everything together, compact and protected on the move. Optionally the Conference Microphone Kit can be equipped with an AC power adaptor, for potentially unlimited power.

## Specifications

### Characteristics

Type	Electret condenser microphone
Mono / Stereo	2 x Mono
Impedance	1.9 k $\Omega$ $\pm$ 30%
Directionality	Omni-directional

### Power Supply

Power Supply	Plug-in power system , rated voltage: 1.5 - 9V
--------------	--

### Interfaces Input

Microphone sensitivity / gain	- 38dB/kHz- (Dictation Mode)-
-------------------------------	-------------------------------

### Dimensions

Dimensions ( $\emptyset$ )	12.2mm $\emptyset$ x 64mm
Cable length	2.5m
Weight	54g (microphone only)

### Frequency response

Frequency response	20 - 20000Hz
--------------------	--------------

### Technical Data

Input	1.5 V - 9 V
Plug Type	3.5 $\emptyset$ mm mini-jack