

ME31 Compact Gun Microphone

- The directional microphone which can be used in various ways such as recording a lecture and a field sound
- The grip which can be attached to the microphone stand and the tripod is supplied
- The wind screen is supplied to decrease the wind noise
- The metal cutting body realized high rigidity
- The stand can be placed on a table with the grip attached



Allows recording from a distance

The ME-31 is a good choice for outdoor use or lecture recording due to its construction. The directional design limits interference from nearby sound sources. This is useful for recording a particular voice or signal that would otherwise be obscured or overpowered by other sources. For example, the ME-31 can help capture a keynote speaker at a conference without recording a lot of chatter from attendees.

Specifications

Characteristics

Type	Electret condenser microphone
Mono / Stereo	Monaural
Impedance	1.1 Ω
Directionality	Uni-directional

Interfaces Input

Microphone sensitivity / gain	-32.5 dB \pm 4 dB
-------------------------------	---------------------

Dimensions

Dimensions (\emptyset)	21mm \emptyset x 155mm
Cable length	1.5m
Weight	97.5g including cable

Frequency response

Frequency response	70 - 15.000Hz
--------------------	---------------

Technical Data

Input	2 V - 5 V
Plug Type	3.5 \emptyset mm mini-jack

Power Supply

Power Supply	Plug-in power system
--------------	----------------------