

# AS-7032 Transcription Kit Transcription Kit

- Seamless interface to Dragon© / Dragon NaturallySpeaking
- Playback: DSS Pro / DSS / WAV / WMA / MP3
- For mobile and stationary dictation
- Playback of encrypted dictations (DSS Pro)
- Transcription management software (ODMS)
- Playback control with your thumbs
- Variable playback speed



## Most comfortable and intelligent hand wrist rest

This transcription kit is designed to make the transcription (speech to text) of your audio recordings most comfortable. Simply, because you can control the software audio player with your thumbs while listening and typing. The included Olympus Dictation Management System (ODMS) Software allows managing multiple dictations from multiple senders. In case both ODMS and Dragon© (Speech Recognition software by Nuance) are installed the dictation files can be automatically pre-transcribed. Even multiple dragon user profiles can be associated to certain author IDs (1:1) for automatic processing.

## Specifications

### Main Specifications of Controller

Device	RS32 Hand Controller (Check product website for more details)
Number of controls	3 buttons
Configurable controls	Yes (via ODMS)
Detachable hand wrist rest	Yes
Nonslip mat	Yes
Connectivity	USB plug
Cable length	1.5m
Weight	340g
HxWxD	60 x 300 x 21mm

### Main Features of Headphone

Device	E62 (Check product website for more details)
Wearing style	Under-the-chin
Cable length	3m
Connector	3.5mm, stereo, right angled
Connector finish	Gold plating
Weight	35g
Impedance	16Ω
Maximum power input	10mW
Sensitivity	100dB

### Main Features of Transcription Software

Version	ODMS - Transcription Module
Professional audio player	Yes
Individual hand controller configuration	Yes
Variable playback speed	0.5 - 2 x
Noise Cancel	Yes
Tone control	Yes
Level meter control	Yes
Languages of GUI	EN, DE, CZ, ES, FR, NL, PL, RU, SV
Auto-backspace	0- 5s
Transcribe bar	Customizable
Audio codecs	DSS Pro / DSS / WAV / WMA / MP3
Playback encrypted DSS Pro files	Yes
Dictation send/receive method	Shared folder in LAN FTP Drag&Drop from E-mail
E-mail settings	POP3/SMTP Microsoft Outlook Novel GroupWise Lotus Notes
Sort functions in dictation list view	Individual colours for different status Sort (ascending/ descending) Filter
Dictation download folders	1 - 7
Dictation routing / workflow rules	Yes
Recording function	Yes
Split dictation	Yes
Installation wizard	Yes

### Support of Speech Recognition by Nuance\*

	* Speech Recognition software not included
Pre-transcription via background speech recognition	Yes (automatic processing)
Train & adapt user profiles of several authors	Yes
Supported speech recognition software by Nuance	Dragon Naturally Speaking version 10 SP1-15 (Professional/Legal) Dragon Medical Practice Edition 2 & 3

## Operating Systems & Requirements

System Requirements Refer to particular product pages of  
kit items