

M.ZUIKO DIGITAL ED 60mm 1:2.8 Macro

- Fast aperture of 1:2.8
- Dust & splashproof
- Internal focus system and floating lenses
- Fixed body length internal focus system with MSC mechanism
- Robust, lightweight design
- Display for shooting distance and magnification
- ZERO (Zuiko Extra-low Reflection Optical) coating for reduced reflection
- Comfortable shooting with manual focus



The master in macro precision

This macro lens excels in image quality, versatility and resilience. Easily get shots at a close range in true (1:1) life size with razor-sharp details and circular bokeh. When shooting with the OM-D E-M1, the superb image quality is boosted even more thanks to focus stacking: a series of eight images with different focus points is shot and merged to produce an image with increased depth of field. This lens is also dust and splashproof, with a protective coating for the lens elements.

All M.ZUIKO lenses are compatible with the entire range of OLYMPUS PEN and OM-D cameras as well as other MFT cameras.

Specifications

Focal Length

Focal length	60mm
Focal length (equiv. 35mm)	120mm

Lens Construction

Lens configuration	13 elements / 10 groups
HR elements	2
E-HR elements	1
Lens mechanism	Inner focus with screw drive mechanism
Angle of view	20°
Closest focusing distance	0.19m
Maximum image magnification	1.0x (Micro Four Thirds) / 2.0x (35mm format)
ED lens elements	1

Aperture

Number of aperture blades	7 Circular aperture diaphragm for natural background blurring
Maximum aperture	1:2.8
Minimum aperture	1:22

Dimensions

Filter diameter	46mm
Length	82mm
Diameter	56mm
Weight	185g

Application

Recommended Uses	Portrait Nature Travel Macro
------------------	---------------------------------------

Pro Features

Dust, splash & freezeproof	Yes
----------------------------	-----